

HERMANN *S*ÄCKLE

USER MANUAL

3-HAND POCKET WATCH



SETTING THE TIME

1. Pull the crown out to position 1.
2. Turn the crown clockwise or counterclockwise to set the desired time.
3. After setting the time, push the crown back in.